




SCIEXUniversity Samples Snapshots

Each course at SCIEXUniversity is a unique experience. Below you will find a few samples of the learning tools you may encounter while taking a course. You will notice some great reference materials that you will be able to keep for years to come.

Troubleshooting Tree



Lab Exercise

Instrument Maintenance

Objective: To become familiar with the maintenance routines and procedures.

This document is a summary of the steps needed to vent, clean and bring the mass spectrometer back on line as demonstrated during training class given by a SCIEX representative. This document is not meant to take the place of training. If you have not attended the training course at SCIEX, please defer to your SCIEX service representative for instrument venting and cleaning.

1. Computer Maintenance

- Empty the Turing Cache and Temp Directory.
- Delete .tmp files and Temporary Internet Files (if applicable).
- Defragment hard drive.
- Run virus scans.
- Archive the API Instrument, Default, and any additional projects as desired.

2. Cleaning Preparation

- The following materials should be obtained:
 - Lint free wiping cloths (i.e. Kim Wipes) in large and small sizes
 - Foam clean room swabs (organic resistant)
 - Methanol-LC grade; preferably LCMS grade
 - DI water-highest quality
 - Gloves – powder free latex or Nitrile

Reference Cards

| | | |
|--|---|---------------------------------------|
| | Replacing Pump Oil | SCIEX Triple Quad™ and QTRAP® Systems |
| If you are replacing the pump oil, drain the used oil first. Drain the pump oil when the pump is warm. | | |
| | Shut down the system and disconnect the AC mains supply cables of the mass spectrometer and roughing pump from the AC main supply | |
| | Put the oil collection container underneath the oil drain plug | |
| | Use a 10mm hex key to loosen the oil drain plug, and slowly remove the oil drain plug | |
| | Wait while the pump oil drains into the container, and | |

| | | |
|--|------------------------------|------------------------------|
| | Quick Reference Guide | Module Front End Cleaning |
| Full Cleaning – Q0 Region | | |
| | | |
| <small>AB Sciex is doing business as SCIEX. © 2017 AB Sciex. Unless otherwise noted in our product literature, SCIEX products are For Research Use Only. Not for use in Diagnostics Procedures. For more information contact your local sales representative or refer to www.absciex.com. The trademarks mentioned herein are the property of AB Sciex Pte. Ltd. or their respective owners. AB SCIEX™ is being used under license. Document number: GEN-CST-05-5407-A</small> | | |

AB Sciex is doing business as SCIEX.

© 2018 AB Sciex. The trademarks mentioned herein are the property of the AB Sciex Pte. Ltd. or their respective owners. AB SCIEX™ is being used under license. Unless otherwise noted in our product literature, SCIEX products are for research use only. Not for use in diagnostics procedures. For more information contact your local sales representative or refer to sciex.com. Document number: GEN-MKT-07-7750-A



Headquarters
 500 Old Connecticut Path | Framingham, MA 01701 USA
 Phone 508-383-7700
sciex.com

International Sales
 For our office locations please call the division headquarters or refer to our website at sciex.com/offices